



TCMFX

FIRE BOX

User Manual

English

TCM705 Version I

August 2024



Foreword

Thank you for purchasing the TCMFX Fire Box.

The Confetti Maker is manufacturer of biodegradable, colourfast and fireproof confetti products and special effects.

The products we manufacture are used for various events, such as concerts, opening ceremonies, sporting events and theater show productions. With our products your party is guaranteed to be a great success.

"We create experiences"

This manual describes the TCMFX Fire Box.

All information in this manual is important for the safe and proper functioning of the TCMFX Fire Box.

Please read the manual carefully if you are not familiar with this device. The Confetti Maker wishes you lots of fun with your purchase!

© Copyright 2015 The Confetti Maker FX®. This manual and its content is copyright of The Confetti Maker FX®. All rights Reserved.

No part of this manual may be reproduced or transmitted in any form or by any means including photocopying and recording without the written permission of the copyright holder.

The Confetti Maker Reserves the right to make any changes without direct knowLEDge of the customer.

Please contact your supplier for additional information regarding maintenance and repair.

This user manual has been written with care and attention to detail; however, should you find any errors or omissions, please contact your supplier and inform them of your findings.

Please be aware that The Confetti Maker FX® shall not be held liable by the user for any damages, losses or third party claims arising from any uses of this product.



General Safety

WARNING!

Read the manual carefully before using the TCMFX Fire Box.

The Confetti Maker ® is not liable for injury, damage and / or excessive wear resulting from improper maintenance, improper use or modifications to the device.

If you have any questions, issues or problems that do not get discussed in this guide, please tell your supervisor or call/e-mail the technical support from The Confetti Maker®.

TCMFX Fire Box and the manual may not be modified without permission of The Confetti Maker®.

In case of damage or problems, always consult The Confetti Maker® as soon as possible.

3



Table of Contents

Specifications	5
Introduction	6
Using the Fire Box	7
Parts	8
Warranty	9



Specifications

Weight 1,2 KG

Size 16,5 x 16,5 x 7,5 cm (L x W x H)

Voltage 4W

Power 4W

Max switching 16A current

Keep away from:

- · Dust;
- · Corrosive gasses
- · High concentrations of organic gasses.



Introduction

The Fire Box is a the big entertainment switch which you want to press at the highlight of your show.

It features a big red button, safety switch and a Red LED indicator to show the user that the device is armed!

The Red button consist of a 60mm red push button which gives a excellent feeling when pressing.

The 2 step safety switch will remove the danger of accidentally activating the device.

6

Using the Fire Box

WIRING

Power the device by connecting a "Powercon True One" cable to the input of the device.

Connect with another Powercon true one cable from the output of the device to the desired devices that you would like to activate when pressing the button.



ARMING THE DEVICE

The device can be armed by activating the safety switch just above the main big red button. Arming is done by flipping the protective cap up, which exposes the safety switch, and flipping the safety switch. Disarming is done by simply flip the "protective cap" back which also flips the safety switch back.

Whit this you would have 2 steps to arm and 1 step to disarm, making it safer to use.

FIRING THE DEVICE

When the device is armed, the LED on the tip of the safety switch and the letters "FIRE" underneath the big red button wil light up.

By pressing the big red button at this moment wil activate the device!



Parts



- 1. Switched Power Output
- 2. Power Input
- 3. Safety Arm
- 4. Fire Button



Warranty

The Fire Box has a 5 year warranty which will be void if the Fire Box is handled differently than described in this manual.

The warranty is void when the Fire Box has been opened by anyone other than The Confetti Maker.

The Confetti Maker is not responsible for any paint or hardware damaged as a result of rough handling.



CAUTION! Always contact your supplier in case of malfunctions. Never try to repair the Fire Box yourself.



WARNING!

READ THIS DOCUMENT BEFORE INSTALLING OR USING Fire Box. IMPROPER SELECTION, IMPROPER USE, USE BY ANYONE OTHER THAN TRAINED USERS HAVING APPROPRIATE TECHNICAL EXPERTISE OF THE Fire Box CAN CAUSE DAMAGE TO EQUIPMENT OR PROPERTY.

This document and other information from the Fire Box, its subsidiaries and authorised distributors together only provide product installation guidelines and product or system usage options, each of which are intended to operate in conjunction with further investigation by trained users having appropriate technical expertise to facilitate the safe handling and use of the Fire Box.

The Fire Box is not intended to be used or handLED by any users other tan trained users having appropriate technical expertise. The information and documentation contained in our catalog and on the website, www.theconfettimaker.com, is only provided for technical illustration purposes only and may not be used or relied upon as a statement of suitability for use in any particular application. Users, through their own analysis and testing, are solely responsible for assuring that the Fire Box is used in a safe and intended manner with all performance, endurance, maintenance, safety and warning requirements necessary for safe application being met.



DECLARATION OF CONFORMITY

Manufacturer:The Confetti MakerProduct:TCMFX Fire Box

We declare that the above products meet the following European directives and standards:

- · Low Voltage Directive 2006/42/EC
- EMC Directive 2004/108/EC
- RoHS Directive 2002/95/EC

Year of Manufacturing: 2024

Name: The Confetti Maker

Place: Rotterdam
Date: 1-7-2024
Director: H. S. Maikoe

All Technical Trade Centre b.v. Horiestatemengs 26 3077 St. Rotestan Medicitant Int. 0031 - 64 169 20 31





The Confetti Maker BV

Florijnstraat 101 2988 CL - Ridderkerk The Netherlands

E-mail info@theconfettimaker.com Phone +31 10 25 41 111









